




GAS RANGE

MODELS:

MFGS8030RZ0 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W11379945	Bracket, Anti-Tip	20	8016P022-60	Glide, Main Top
	W11642081	Owner's Manual	11	7101P485-60	Screw, Anti-Tip Kit	21	W10530626	Screw
	W11639173	Tech Sheet	12	W11672010	Grate, Bumper	22	W11601635	Griddle
	W11641830	Quick Start Guide	13	W11637551	Spring, Clip	23		Bezel
2		Burner Cap Kit	14	W11295628	Cooktop, Front Bracket		W11374916	W11374916
	W11635764	Black (Set of 4)	15		Frame, Cooktop			FOLLOWING PARTS NOT ILLUSTRATED
3	W11635708	Burner Kit		W11367962	Black	W11334462		Harness, Main
4		Cooktop	16	9780274	Screw	W11454086		Harness, Bake
	W11279786	Black	17	W11366598	Bracket, Spark Module	W11334489		Harness, Cooktop
5		Panel, Manifold	18	W11352019	Spreader, Flame (Left Front and Right Rear)		3196520	Clip, Wire
	W11412239	Black					313438	Clip, Harness
6		Knob, Control		W11352021	Spreader, Flame (Left Rear)		3196896	Clip, Wire
	W11372959	Stainless		W11352018	Spreader, Flame (Right Front)			
7		Grate Kit	19	W11357363	Oval Burner Assembly (Center)			
	W11370698	Black (Set of 3)						
8	W10673618	Screw						
9		Panel, Manifold End Cap						
	W11351704	Stainless (Left)						
	W11351707	Stainless (Right)						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10818365	Module, Spark DSI	11	3196178	Screw
	W11625424	Stainless (Left)	6	3196160	Screw	12	W11371599	Bracket, Control
	W11625421	Stainless (Right)	7		Panel, Lower			
2	W11363806	Shield, Heat		W11625438	Stainless			
3		Panel, Control	8	3196169	Screw			
	W11730197	Stainless	9	W11350452	Spark Module			
4	W11436173	User Interface Assembly	10	W11393669	Cover, Upper Rear			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11402213	Screw	8	W11630470	Valve, Gas (Left Front and Left Rear)	17	W10362924	Screw
2	W10827923	Electrode, Spring				18	3196265	Screw
3	W11300876	Orifice Holder Assembly (12K) (Left Front)		W11279839	Valve, Single (Right Front and Center)	19	W10849722	Orifice (18K) (Left Front, Right Front and Center)
	W11300874	Orifice Holder Assembly (10K) (Left Rear)		W11279837	Valve, Single (Right Rear)		W10849719	Orifice (5K) (Right Rear)
	W11300879	Orifice Holder Assembly (18K) (Right Front)	9	W10224921	Bracket, Aegis		W10907868	Orifice (10K) (Left Rear)
	W11300867	Orifice Holder Assembly (5K) (Right Rear)	10	3196385	Screw			FOLLOWING PARTS NOT ILLUSTRATED
	W11341430	Orifice Holder Assembly (12K) (Center)	11	3400016	Screw		W11370715	LP 5 Orifice Conversion Kit
4	W11384792	Tubing (Manifold to Regulator)	12	W10714060	Element, Broiler		W10838304	Orifice, LP Bake
5	W11637977	Harness, Igniter (Includes Switches)	13	W10184491	Spreader, Flame (Oven)		W11402210	Tie, Wire
6	W11450459	Electrode, Bake	14	9758078	Burner, Bake			
7	W11279814	Manifold Assembly	15	W10818355	Regulator			
			16	W11428831	Electrode (Left Front, Left Rear)			
				W11428858	Electrode (Right Front, Right Rear)			
				W11581944	Electrode (Center)			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11366110	Box, Flue	18	W10031780	Screw	34	3196178	Screw
2	W11279866	Shield, Flue	19	3400080	Screw	35	W11173792	Rack, Oven
3	W10067840	Screw	20	W11734477	Control, Electronic	36	W11644425	Fan, Convection
4		Panel, Side	21	W11491751	Seal, Door	37	W11464547	Bracket, Front Frame
	W11445467	Black	22	W10435470	Brace, Main Back	38	W11373155	Cover, Conv Fan
5	W10137382	Clip, Panel	23	W11379353	Retainer, Insulation (Left)	39	W10516115	Screw
6	W11287215	Bracket, Cooktop Console		W11379943	Retainer, Insulation (Right)	40	W10379120	Screw
7	W10362924	Screw				41	W11625914	Ventilation Assembly, Console
8	3196560	Screw	24	3196560	Screw	42	3400701	Screw
9	W10341186	Front Foot Assembly	25	W11661976	Cord, Power	43	W11411632	Blower, Tube
10	W10058460	Foot, Leveling	26	W10289077	Receiver, Hinge	44	W11642475	Tube, Clamp
11	W11602073	Bottom, Oven	27	W11511828	Switch, Door	45	W11365827	Bracket, Acu
12	W11633068	Sensor	28	W11634772	Light Assembly	46	W11596199	Cover, Side Fan
13	8053967	Baffle, Burner Oven	29	W10571723	Bulb, Halogen 40 Watts	47	8016P022-60	Glide, Main Top
14	8053969	Shield, Heat	30	9761013	Front Door Latch Assembly			FOLLOWING PARTS NOT ILLUSTRATED
15	W11640074	Shield, Lower						
16	W10390008	Base Rail Assembly (Left)	31	W10078370	Rod, Push Latch	W10818362		Insulation, Wrap
	W10390007	Base Rail Assembly (Right)	32	W10107820	Rear Door Latch Assembly	W11407376		Insulation, Back
17	9757239	Rod, Door Switch	33	W10674705	Glide, Drawer Front			

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Door
	W11495825	Stainless
2	3196154	Screw
3	W11417442	Bracket, Handle Mount (Left)
	W11157607	Bracket, Handle Mount (Right)
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10316950	Frame, Glass
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10388635	Hinge, Door (Active)
11		Glass, Outer Door
	W11631954	Stainless (Includes Badge)
12	W10200660	Screw
13	W10327235	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	W11628148	Badge
15	W10440013	Hinge, Door (Active)

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10674708	Glide, Drawer Rear	4		Panel, Drawer Front
2	W10688022	Drawer, Storage		W11190210	Stainless
3	W10462909	Bracket, Mounting	5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		Following Parts Not Illustrated
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		PAINT, TOUCH-UP (1/2oz.)
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	285006	Black
	350930	White
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORY PARTS
	30-48KITRC	Gas Range Connector Kit
	4396096RB	Griddle
	4396923	Broiler Pan and Grid